



3P Technik UK  
WATER MANAGEMENT

# Modena

100 Litres

Art. No. 9000901K



3P Technik UK  
WATER MANAGEMENT

# Modena

100 Litres

Art. No. 9000901K

## Instructions

To fill the Modena, we recommend using the 3P Filter Collector Universal.

Where the water butt cannot be located within 30 cm of the downpipe, longer Long Link Kits are available from your dealer.



The 3P Filter Collector Universal is available in three colours to match your downpipe; black, grey and brown.



### 5. Tank-to-tank Connection

If you wish, you can connect two Modena Water Butts together using the drain down points near the base at the rear of each tank. A 3P 3/4" Tank to Tank Connection Kit is ideal for this. Measure the distance between the threaded ports before ordering the required length of hose in the Connection Kit from your water butt supplier.

The Modena is delivered with an accessory kit which includes a chrome tap, wall bracket, and screws. The top has a removable filter and fixed shelf to allow for decorative stones (not included) to be placed.

**If in any doubt during installation, please consult a professional tradesperson or the supplier of your filter or diverter.**

# Modena

## 100 Litres

Art. No. 9000901K

### 1. Setting up

Site the rain tank on a firm, level surface adjacent to a downpipe.

Read through these instructions and the 3P Filter Collector Instructions or other rain diverter instructions fully before proceeding.

**If in any doubt during installation, please consult a professional tradesperson or the supplier of your filter or diverter.**



### 2. Fitting the 3P Filter Collector Universal Link Kit

#### Marking Out

Measure down 60mm (approx) from the top of the water butt. This position is ideal for all connections of 32mm (1 1/4") or less and mark the point.

#### Hole Cutter Selection - 32 mm

To fill the water butt with the recommended 3P Filter Collector Universal, select the 32 mm flat bit provided with the 3P Filter Collector Universal Kit.

#### Drilling

Offer the 32mm drill to your marked point, proceed to drill. If you are not fitting a 3P Filter Collector Universal, double check you are drilling the correct sized hole for your chosen connection set.



3P Technik UK  
WATER MANAGEMENT

# Modena

## 100 Litres

Art. No. 9000901K

### 2. Continued...

#### Attaching the Hose Tail with Back-Nut

Hold the back nut on the inside of the hole and screw on the hose tail and rubber grommet on the outside.

**Note:** The basket can be lifted for easier access.



### 3. Connecting the Tap

Screw the 3/4" brass tap provided in the Kit into the 3/4" BSP connection thread. If necessary, use PTFE tape when installing the tap to create a more watertight seal and to allow the tap to sit in the correct position.

### 4. Fixing the Wall Bracket

Fill the tank with water before attaching the wall bracket to avoid deflection. The bracket is optional.

#### Winter Care Precautions

During extremely cold winters, where daytime temperatures are below zero for several days, it is wise to ensure that the tank is only about 2/3rd's full and the water supply turned off. This will prevent the frozen water from expanding and damaging the tank.



# Modena

## 100 Litres

Art. No. 9000901K

# Modena

## 100 Litres

Art. No. 9000901K