# INSTALLATION GUIDE PLASTERBOARD

Breathaplasta Universal is ideal as a healthy skim coat applied directly to conventional gypsum plasterboard without the need for a primer. Universal is a fast-setting, multi-purpose, hemplime plaster designed for rapid build-up onto a wide range of backgrounds.

#### Important notes for use on plasterboard:

- Ensure plasterboard is conventional gypsum plasterboard (ivory coloured paper).
- Specialist plasterboard requires a primer to be used before plastering. Examples include: moisture resistant (green), fire resistant (pink), and acoustic (blue).















Add 1 x 18kg bag of Universal to approx. 8 litres of clean water.





Mix the plaster using a paddle mix for at least 2 mins. Leave the mix to stand for 2 mins, then mix again for 1 min.



Apply at least 2 coats of Universal. Each coat should be at 2mm thick.





Setting time per coat of Universal is approx. 45-60 minutes.



Run a clean trowel over the surface of the plaster for a smooth finish. Use a sponge float for more textured finishes.





For a smooth finish, moisten the surface of the plaster with a fine mist spray bottle to help polish the surface with trowel.

# **Equipment Required:**

Breathaplasta Universal, clean water, brush or mister, hawk, trowel and plastering tools.

#### Surface preparation:

No treatment or priming is required before applying plaster to conventional plasterboard. Specialist plasterboard requires the use of a primer (bonding agent) before plastering.

## Recommended plaster thickness:

4mm total thickness (2 x 2mm coats).

#### Recommended plaster application:

- 1. Base coat of Universal 2mm.
- 2. Top coat of Universal 2mm.
- 3. Moisten top coat using a fine mist spray bottle to help trowel to a smooth finish.

## Coverage per 18kg Universal bag:

5m<sup>2</sup> at 4mm thickness

#### Setting time per coat:

45 - 60 minutes

