



Technical data

Material		
Backing	Special PP fleece	
Adhesive	Water-resistant SOLID adhesive	
Release film	Silicone-coated paper	

Property	Regulation	Value
Colour		Black
Outdoor exposure		6 months
Bond durability, non-aged/aged	EN 17990	Passed
Can be plastered over		Yes
Application temperature		Above -10 °C ; 14 °F
Temperature resistance		Permanent -50 °C to 90 °C ; -60 °F to 194 °F
Storage		Cool and dry

Areas of application

Exterior use: Creation of windproof seals for breather membranes (weather-resistive barriers, WRBs) from the SOLITEX FRONTA series and for roofing underlays. Windproof sealing of wood-based panels as underlays. Airtight taping of on-roof and retrofit vapour control and airtight membranes.

Interior use: Airtight taping of vapour control and airtight membranes and of airtight wood-based panels.

All taped joints, indoor and outdoor, can be implemented between similar components or else with adjacent structural elements with a smooth, non-mineral surface (e.g. pipe penetrations, roof windows).

Supply form

Art. no.	Length	Width	Splits on release film	Weight	Sales unit	Container	GTIN
1AR02072	30 m	60 mm	No split	0.7 kg	20	480	4026639220721
1AR02784	30 m	100 mm	50 50 mm (2" 2")	1.27 kg	2	288	4026639227843
1AR02628	30 m	150 mm	75 75 mm (3" 3")	1.9 kg	2	192	4026639226280

Advantages

- ✓ Adheres reliably – even if moisture is present: water-resistant SOLID adhesive
- ✓ Becomes practically invisible: discreet black backing fleece not visible behind open-jointed cladding
- ✓ Adheres in a permanent, reliable manner: UV-stable behind open-jointed cladding
- ✓ Flexible on-site work sequencing: 6 months of outdoor exposure
- ✓ Easy to work with: very malleable fleece backing that can be torn by hand
- ✓ Subsequent work can be started quickly: fleece backing can be plastered over directly
- ✓ Construction in adherence with standards: for airtight sealing in accordance with DIN 4108-7, SIA 180 and RE 2020
- ✓ Excellent values in hazardous substance testing, has been tested according to the ISO 16000 evaluation scheme

Substrates

Clean subsurfaces before applying tape. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable; if necessary, subsurfaces should be stabilised or renewed.

Permanent adhesion is achieved on all pro clima internal and external membranes, on other vapour control and airtight membranes (e.g. those made of PE, PA, PP and aluminium) and on other underlay and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesion and taped connections are possible with planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), rigid foam insulation materials that can be plastered over, and hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels).

Pre-treatment with TESCO PRIMER is required in the case of adhesion to wood-fibre underlay panels or on smooth, mineral subsurfaces. It may be necessary to apply a bead of adhesive sealant – e.g. ORCON F – underneath the tape to achieve reliable seals on rougher surfaces.

The best results in terms of reliability are achieved on high-quality subsurfaces. Particular care is necessary when working with older or multi-layer subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests may be necessary in certain cases. Pre-treatment of the subsurface with TESCO PRIMER will improve the adhesive bond.

General conditions

Taped joints must not be subjected to tensile forces. Once membranes have been taped, the weight of the insulation material must be supported by laths. Adhesion should be supported by additional laths, if necessary. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure.

Windproof, airtight or rainproof sealing can only be achieved on vapour control or underlay/facade membranes that have been installed without folds or creases. Ventilate continuously and systematically to prevent the build-up of excessive humidity; use a dryer if necessary. When plastering, please observe the recommendations of the plaster manufacturer for non-absorbent substrates. A bonding course may be necessary.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

MOLL
bauökologische Produkte GmbH
Rheintalstraße 35 - 43
D-68723 Schwetzingen
Fon: +49 (0) 62 02 - 27 82.0
eMail: info@proclima.de